

MIRACOL

FINING OF WINES WITH HIGH PROTEIN CONTENT TREATMENT BEFORE FILTRATION

CHARACTERISTICS

MIRACOL is an activated calcium bentonite with an exceptional clarifying and protein adsorption potential.

OENOLOGICAL PROPERTIES

- **MIRACOL** gives excellent results for both white and red wines that are difficult to filter.

APPLICATIONS

- The use of **MIRACOL** is similar to that of bentonite but at much lower dosages: 10 to 20 g/hL.
- **MIRACOL** is mainly used with white wines that are difficult to treat and that would otherwise require large amounts of conventional bentonite to be treated efficiently.

DOSAGE

Average doses: 5 to 25 g/hL.

5 g/hL is the minimum dose recommended for wines that are already clear or contain only small amounts of proteins.

It is possible to exceed the dose of 20g/hL with wines that are very difficult to clarify.

Due to its high efficiency, treatment with **MIRACOL** produces a significant amount of lees: expect a volume of lees of around 4%, for treatment with 20g g/hL and a settling time of at least 4 days.

INSTRUCTIONS FOR USE

Sprinkle **MIRACOL** into water while stirring (1kg for 25 to 30 L of water).

Stir again after leaving to stand for 1 to 2 hours.

Leave it to swell for 12 to 24 hours (at least 4 hours).

Add this suspension rapidly and vigorously using a metering pump or a DOSACOL (fining connection) either during a transfer or pump-over.

Successful fining depends on pre-swelling and the way in which the fining agent was added.

It is preferable to allow the lees to settle for a few days before racking or filtration.

The lees can be recovered and filtered to reduce their volume.

Precautions for use:

Product for oenological and specifically professional use.

Use in accordance with current regulations.

PACKAGING

1 kg bags - boxes of 20 x 1 kg

25 kg bags.

STORAGE

Store unopened, sealed packaging away from light in a dry, odour-free environment.

Once opened use rapidly.

The information provided above is based on our current state of knowledge. This information is non-binding and without guarantee, since the conditions of use are beyond our control. It does not release the user from complying with existing legislation and safety data. This document is

the property of SOFRALAB and may not be modified without its agreement.

SAS SOFRALAB - 79, av. A.A. Thévenet - CS 11031 - 51530 MAGENTA - France

Tél. : + 33 3 26 51 29 30 - Fax : + 33 3 26 51 87 60 - www.martinvialatte.com