



NUTRICELL® FINISH

100% organic nutrient for perfect control of the end of alcoholic fermentation



End of alcoholic fermentation

Complex nutrition

To restart stuck alcoholic fermentation



OENOLOGICAL GOALS

- Contains yeast hulls. Thanks to their detoxifying effect, these improve the end of fermentation in cases of yeast stress (low temperature, strong clarification, high alcohol content, etc.)
- Yeast autolysates particularly rich in amino acids
- Amino acids are assimilated by the yeast to resynthesize sugar transporter proteins and thus reactivate AF
- Autolysates also release vitamins and trace elements necessary for yeast metabolism



DOSAGE

Recommended dose: 20 to 40 g/hL depending on the nutritional needs of the yeast and the assimilable nitrogen content of the must.

Maximum legal dose according to current European regulations: 160 g/hL



PACKAGING



**1 KG
10 KG**



STORAGE

Store unopened, sealed packages away from light in a dry, odour-free environment.
Do not allow to freeze.
Once opened, use up rapidly.

The information provided here is based on our current state of knowledge. This information is non-binding and without guarantee, since the conditions of use are beyond our control. It does not release the user from complying with existing legislation and safety data. This document is the property of SOFRALAB and may not be modified without its consent.



INSTRUCTIONS FOR USE

Disperse **NUTRICELL® FINISH** in 10 times its weight in water or must (1kg per 10L).
Incorporate into the volume to be treated

Precautions for use:

Product for oenological and specifically professional use.

Use in accordance with current regulations.

Suggestion for use: Lipid / Nitrogen imbalance as in the case of strongly settled or deficient musts, or high alcohol content

Organic nitrogen: Limits catabolite repression and promotes the production of volatile compounds

*Source of ergosterol + fatty acids
Rebalances the medium*

In the presence
of oxygen,
S. cerevisiae is
able to synthesise
ergosterols



Yeast hulls
DAP if necessary



Sequential supplementation

Fermentation



TEST RESULTS

Nitrogen/lipid imbalance leads to cell death

Figure 1: Cell population densities determined by flow cytometry at the stationary phase

Strain	Composition of synthetic medium		Cell population (10 ⁶ cells/mL)
	Assimilable nitrogen (mg/L)	Lipid factor (%)	
EC1118	425	100	202.6 ± 9.9
EC1118	425	5	49.2 ± 4.5
EC1118	142	100	106.5 ± 12.3
EC1118	142	5	44.6 ± 6.3
EC1118	71	100	68.4 ± 4.6
EC1118	71	5	39.5 ± 8.8