



ORIGIN RED

PVP/PVI based complex with adsorbing and chelating properties for fruity and supple red wines.







Detoxifies the medium

Limits the negative impact of Brettanomyces

Resistance against oxidation



OENOLOGICAL GOALS

- Chelating properties: elimination of heavy metals (Fe, Cu).
- Enables frank, fast alcoholic fermentation.
- Decreases concentrations of phenolic acids, precursors of volatile phenols following the development of Brettanomyces and easily oxidisable compounds.
- By its 2 properties: limits the oxidation of wines and improves their longevity.
- Presence of inactivated dry yeast (SIY): during yeast autolysis, adds volume and structure to wines.



DOSAGE

20 to 80 g/hL.

Maximum legal dose according to current regulations: 250 g/hL



PACKAGING







STORAGE

Store unopened, sealed packages away from light in a dry, odour-free environment.

Do not allow to freeze.

Once opened, use up rapidly.

The information provided here is based on our current state of knowledge. This information is non-binding and without guarantee, since the conditions of use are beyond our control. It does not release the user from complying with existing legislation and safety data. This document is the property of SOFRALAB and may not be modified without its consent.








Chelation:

A physico-chemical process during which a complex – the chelate – is formed between a ligand, known as the chelator (or chelating agent) and a metal cation (or atom), which is then complexed, i.e. chelated.

→ Reaction with heavy metals



GOOD TO KNOW!

PVP / PVI
The central active
ingredient

Adsorption:

A physico-chemical phenomenon whereby two molecules interact with each other, forming low-energy bonds

→ Reaction with phenolic acids





INSTRUCTIONS FOR USE

Dilute **ORIGIN RED** in 10 times its weight of must. After adding, homogenise well by pumping over a volume of the tank.

Precautions for use:

Product for oenological and specifically professional use. Use in accordance with current regulations.



TEST RESULTS

Reduction of copper concentration with the addition of ORIGIN RED

